

Using Playaway Launchpad

Powering On/Off

To turn on, hold down for 3 seconds (located on the right hand side)

To put in standby mode, press one time briefly. This will help preserve your battery power.

To turn off, hold down for 3 seconds.

Navigating Launchpad

App menu screen

Customize your avatar by redeeming discovery points

Visit informational console to view "Play Analytics"

Use the Android navigation bar to exit apps or return to home page. To make Android navigation bar appear, touch bottom of screen.

Exit current screen or "go back"

Return to home page (Reset or continue as current user)

Troubleshooting

Not turning on?

Your Launchpad needs a power boost. Charge for five minutes using the provided power cord.

Need more help?

Please contact cx@playaway.com or 877.893.0808